



# HQ Impact Screen Material

## *Maintenance Tips*

### **General Use**

- Always use clean clubs and balls
- Ensure all balls do not have nicks / cuts
- Use proper mounting and golfing methods

### **Normal Cleaning**

- Remove any attachments (ie: netting) if possible
  - Warm water wash
  - No bleach or detergents
  - Wash dark colors separately
  - Tumble dry synthetic setting

### **Stains**

- Results may vary according to the stain
  - Use mild dishwasher soap
  - Test in an inconspicuous location

### **Wrinkles**

- Steam w/ cloth over steamer to prevent water stains
  - Low Setting to prevent melting of the yarn
  - Steam iron flat on turf flooring for best results
- Pressing too hard may produce waves / puckering
  - Use only distilled water

*Use the above information as a general guideline only. Use and care at your own risk – it is best to exercise caution when caring for your screen. Par2Pro accepts no liability for the HQ Impact Screen Material. Copyright 2012 Par2Pro, a division of 1363150 Alberta Ltd.*

**Par2Pro**

a division of 1363150 Alberta Ltd.

Phone (780) 666-6442 Fax (780) 642-2522 Email [info@par2pro.com](mailto:info@par2pro.com) Web [par2pro.com](http://par2pro.com)